

Low Profile Canopy (LPC) Installation

The Low Profile Canopy (LPC) can be used where extra wiring space is needed.

1. Mount the LPC in the desired position by running the four long screws supplied with the LPC through the four corner holes. Holes should be AWAY from surface.
 - A. Run system cable into the hollow center of the LPC through a hole in the mounting surface. Or if the cable is a surface run, under one side of the LPC. If running cable under the LPC do not over tighten mounting screws as this may damage cable.
 - B. If tree mounting the fixture, you may wish to mount the LPC to a piece of redwood, finish the remainder of the assembly procedure as described below, and mount entire assembly to the tree with a UV resistant bungee cord.
2. Complete fixture wiring. Keep leads short so wiring, wire nuts, etc... will fit inside the LPC's hollow center.
3. Use the two screws supplied with the fixture to fasten it to the top of the LPC.

Nightscaping® • 1705 E. Colton Ave, Redlands, CA 92374 • (800) 544-4840 • (909) 794-2121
Fax: (909) 794-7292 • www.nightscaping.com • info@nightscaping.com

Low Profile Canopy (LPC) Installation

The Low Profile Canopy (LPC) can be used where extra wiring space is needed.

1. Mount the LPC in the desired position by running the four long screws supplied with the LPC through the four corner holes. Holes should be AWAY from surface.
 - A. Run system cable into the hollow center of the LPC through a hole in the mounting surface. Or if the cable is a surface run, under one side of the LPC. If running cable under the LPC do not over tighten mounting screws as this may damage cable.
 - B. If tree mounting the fixture, you may wish to mount the LPC to a piece of redwood, finish the remainder of the assembly procedure as described below, and mount entire assembly to the tree with a UV resistant bungee cord.
2. Complete fixture wiring. Keep leads short so wiring, wire nuts, etc... will fit inside the LPC's hollow center.
3. Use the two screws supplied with the fixture to fasten it to the top of the LPC.

Nightscaping® • 1705 E. Colton Ave, Redlands, CA 92374 • (800) 544-4840 • (909) 794-2121
Fax: (909) 794-7292 • www.nightscaping.com • info@nightscaping.com

Low Profile Canopy (LPC) Installation

The Low Profile Canopy (LPC) can be used where extra wiring space is needed.

1. Mount the LPC in the desired position by running the four long screws supplied with the LPC through the four corner holes. Holes should be AWAY from surface.
 - A. Run system cable into the hollow center of the LPC through a hole in the mounting surface. Or if the cable is a surface run, under one side of the LPC. If running cable under the LPC do not over tighten mounting screws as this may damage cable.
 - B. If tree mounting the fixture, you may wish to mount the LPC to a piece of redwood, finish the remainder of the assembly procedure as described below, and mount entire assembly to the tree with a UV resistant bungee cord.
2. Complete fixture wiring. Keep leads short so wiring, wire nuts, etc... will fit inside the LPC's hollow center.
3. Use the two screws supplied with the fixture to fasten it to the top of the LPC.

Nightscaping® • 1705 E. Colton Ave, Redlands, CA 92374 • (800) 544-4840 • (909) 794-2121
Fax: (909) 794-7292 • www.nightscaping.com • info@nightscaping.com