

Nightscaping® ACE Direct Burial Cable Connector #1525-DB



Installation Instructions

1. Before stripping cable ends, slide insulation tubing over cable end, then along cable out of the way.
2. Strip cable ends approx. 5/8 inch.
3. Insert stripped cable end(s) into either end of ACE connector barrel.
4. Using the Allen wrench provided, tighten set screw firmly.
5. Strip other cable end(s), insert in other end of ACE connector, tighten with Allen wrench.
6. Retighten both set screws with Allen wrench.
7. Slide insulation tubing over brass connector, heat evenly with hand-held torch until tightly sealed.

Voltage and Current rating 30V, 25 AMPS

Quantity and Conductor Size	Combinations such as:
1-#8 2-#10	1-#8 + 1-#14 + 2-#18
3-#12 4-#14	1-#10 + 2-#16 + 2-#18
6-#16 8-#18	1-#12 + 1-#14 + 3-#16 + 2-#18
	2-#14 + 1-#16 + 2-#18
	3-#16 + 5-#18

Nightscaping

Nightscaping® by Loran Inc.

1705 E. Colton Ave • Redlands, Ca. 92374

(909) 794-2121 • Fax: (909) 794-7292 • Toll Free (800) 544-4840

Email: wlocklin@nightscaping.com • Web: www.nightscaping.com